

# Determine Ignition Edition Installed

```
from com.inductiveautomation.ignition.common.model import PlatformEdition
print PlatformEdition.isEdge()
# or
# print PlatformEdition.isMaker()
# print PlatformEdition.isCloud()
# print PlatformEdition.isStandard()
```

---

Revision #1

Created 8 January 2025 15:15:59 by Michael Flagler

Updated 8 January 2025 15:16:51 by Michael Flagler