

Determine Ignition Edition Installed

```
from com.inductiveautomation.ignition.common.model import PlatformEdition
print PlatformEdition.isEdge()
# or
# print PlatformEdition.isMaker()
# print PlatformEdition.isCloud()
# print PlatformEdition.isStandard()
```

Revision #1

Created 2025-01-08 15:15:59 UTC by Michael Flagler

Updated 2025-01-08 15:16:51 UTC by Michael Flagler